



Installation instruction for PSP landing mat type ETP-PSP40304213 for aircraft use:


1. even up the natural underground
2. compress - the tighter the underground, the higher forces will be absorbed
3. surface the complete area with 200 mm sand - without stones at the surface
4. even up the sand and compress it - the tighter the underground, the higher forces will be absorbed
5. lay out the PSP planks



6. secure them from shifting by 2 locking spring clips each



7. to avoid horizontal movements: insert one ground nail trough a hole in the plank and ram it into the ground



to avoid horizontal movements:
one ground nail retroserrated 600 mm long per PSP plank